

MARBOCOTE 625X MOULD RELEASE APPLICATION

TO USE MARBOCOTE 625X THE PRINCIPAL IS TO WIPE ON A WET FILM, THIS FILM MUST BE ALLOWED TO DRY FOR 10 MINUTES AT LEAST, THEN WITH A SEPARATE CLOTH BUFF OFF TO A GLOSS

-
IF YOU BUFF TOO QUICKLY YOU WILL BE REMOVING MOST OF THE PRODUCT & PERFORMANCE WILL BE POOR

- SHAKE THE CAN WELL
- USING A WPPP60 CLOTH APPLY A GENEROUS EVEN FILM, ALLOW THE FILM TO HAZE, CHECK NO AREAS HAVE BEEN MISSED, TOUCH UP AS NECESSARY
 - LEAVE FOR AT LEAST 10 MINUTES, 15 TO 20 MINS IF YOU CAN
 - USING A FRESH CLOTH POLISH GENTLY TO A GLOSS, NO NEED TO RUB HARD, TURN THE CLOTH FREQUENTLY.
 - WHEN STARTING UP AFTER A SERVICE OR A NEW MOULD APPLY AFTER THE FIRST & SECOND PULLS IF POSSIBLE, IT MUST BE DONE AT LEAST AFTER THE SECOND
 - RE-APPLY AS REQUIRED

SPACE FOR NOTES